

# **Indoor VHF Low-profile Omni Antenna**

## **IXL-EYN-H2P**

VHF Low-Profile, 134-176/340-570/617-960MHz, N-Female, UL-94-VO rated

- VHF omni-Antenna covering 134-175/ 340-570/ 617-960MHz (VHF/UHF/700/800 Public Safety)
- Low-profile and suitable for indoor application
- Compact and cost-effective design



**Electrical Specification** 

Zioon iour op ooijiouoion			
Product Model		IXL-EYN-H2P	
Frequency (MHz)	134-176	340-570	617-960
Gain (dBi). Typical	-0.5	1.2	3.5
Polarization		Horizontal	
Beamwidth Horizontal (°)		360	
VSWR. Typical	1.8	1.8	1.5
Average Power, max (W)		50	
Impedance (ohm)		50	


## **Mechanical Specification**

Dimension Diameter, height (in/mm)	15.16x14.09x0.06 / 385.0x358.0x1.6
Weight (lb./kg)	1.17 / 0.53
Shipping Dimension(in/mm)	15.94x14.96x1.77 / 405.0x380.0x45.0
Shipping Weight(lb./kg)	1.81 / 0.82
Material & color	White
Flammability	UL-94-V0
Mounting/Connector type*	Ceil Mount, N-female
	Option: High Ceiling or Junction Box installation (MT-ND-EY)

## **Environment & Compliance**

Indoor	
-55°C to +70°C	
Up to 95%	
Compliant	
IP-54*	

#### Antenna Pattern



<sup>\*</sup>Note: Recommended for indoor application and the antenna can be used "outdoor garage rated."

<sup>\*</sup>Note: Not recommended for use with metal J boxes directly. Plastic or fiberglass J boxes are acceptable.


<sup>\*</sup>Note: For metal J box installation, recommended to install the antenna with MT-ND-EY as spacer.



#### Installation


#### 1. Standard Installation

Unit: inches [mm]



#### Installation

- 1. Drill four ¼" (Ø6mm) mounting holes on the ceiling. Please refer the drawing
- 2. Insert plastic anchors(M6) in the holes
- 3. Insert mounting plastic screw caps on the antenna mounting holes
- 4. Locate the antenna on the four mounting holes on the ceiling
- Insert screws and then tighten the screws.
  Once completely tighten the screws, push plastic screw caps to cover the screw head



#### 2. Optional installation

For Junction box installation. Please refer to MT-ND-EY (UL-94-V0 rated) installation instructions.

